

Epson® R2400

SET-UP

Media settings:

RC Glossy }
FB Glossy } Premium Glossy Photo Paper
FB Smooth Glossy }

RC Luster } Premium Luster Photo Paper

FB Supreme Matte } Enhanced Matte Paper

Mode: Advanced

Print Quality: Best Photo or RPM

High Speed : OFF

Color Management: OFF (No Color Adjustment)

These profiles are considered generic and are carefully produced under optimum conditions. However, your conditions may vary and the results may be different. It is always recommended that you create your own profiles that meet your particular conditions and standards.